

AECO RCA JACK

Assembly

1. Remove the nut [111] and washer [121]
- 2.1. For solder type: Please remove the ring [311&312] and the screw [321&322] first while soldering cable.
- 2.2. For screw type: Please remain the ring [311&312] and the screw [321&322].
3. Please put the body [211] through the opening gap from the inside of plate.
4. please lock the nut and washer on the body, no need to fasten them in order fine tuning later,
- 5.1. for solder type: please solder the cable (without jacket)
- 5.2. Please lock the cable (without jacket) after loose the screw on the ring, Please turning the body to obtain the space to lock another screw.
6. please lock the nut.

