

# AECO TRS 3.5 PLUG

---

## Assembly

1. We recommend to peel off the cable jacket and per conductor wire insulation.
2. Depends on cable size to decide whether use sleeve (ID 4.5mm) [311], or without sleeve (ID6.5MM) [301].Then through into cable.
3. Contact the cable with per channel by soldering.
4. Lock the shell and body [203],
5. Please lock the cable and shell with a screw M3x4mm [321] or M3x3mm [322].

