

AECO TRS 6.3 PLUG

Assembly

1. We recommend to peel off the cable jacket and per conductor wire insulation.
2. Depends on cable size to use small POM sleeve (ID 6.5mm) [312], or bigger POM sleeve (ID 8.5mm) [311] or without POM sleeve (ID10.5MM) [301].Then through into cable.
3. Contact the cable with per channel by soldering.
4. Lock the shell and body [203],
5. Please lock the cable and shell with a screw [321 / 322].

