

# AECO BINDING POST

---

## Assembly

1. Remove the nut [131] and washer [141]
- 2.1. For solder type: please remove the ring and the screw first. [111]
- 2.2. For screw type: please remain the ring and the screw. [111]
3. Please put the body through the plate opening gap from the outside of plate.
4. Please lock the nut [131] and washer [141] to the body, no need to fasten them in order to fine tuning later.
- 5.1. For solder type: please solder the cable (without jacket)
- 5.2. For screw type: please lock the cable (without jacket) in the ring with a screw [121].
6. Please lock the nut [131].

